Service




NOTE: Numbers in parenthesis in the text refer to the reference numbers in the figures and in the parts list.

Disassembly

- 1. Follow the **Pressure Relief Procedure**, page 20.
- 2. Remove gun for service:
 - a. **With Manifold:** Use the 4 mm allen wrench supplied to unscrew the two

- screws (16) and remove the gun from the manifold.
- Without Manifold: Disconnect the air and fluid hoses. Remove the gun from the mounting arm.
- 3. Remove the air cap retaining ring (21) and air cap (5).
- 4. Remove the fluid adjustment knob (11) and spring (10).
- 5. Pull the piston (7) and fluid needle (6) out of the back of the gun.



26 313869M

- 6. Use a 1/16 hex wrench to loosen the fluid needle set screw (7a). Remove the needle (6) from the piston (7).
- Check the fluid needle (6) for damage or excessive wear. Replace the needle if necessary.

NOTICE

The needle and tip are permanently bonded. To prevent damage to the needle, do not try to separate.


- 8. Use the 10 mm hex nut driver to remove the fluid packing nut (2).
- 9. Use the 10 mm wrench to remove the nozzle (4).

Reassembly

- Lightly grease the new nozzle (4), which includes o-ring (3). Use the 10 mm wrench to install the nozzle. Torque to 155-165 in-lb (18-19 N•m).
- 2. Install the new air cap assembly (5, includes air cap, o-ring, washer, and alignment pin) and the retaining ring (21).

NOTE: Be sure to move the alignment pin if you want a horizontal spray pattern. See **Position Air Cap**, page 18.

- Use the 10 mm hex nut driver to install new fluid packing nut (2, includes o-ring). Torque to 80 in-lb (9.0 N•m).
- Insert the new needle (6) in the piston (7). Apply medium-strength thread sealant to the setscrew (7a). Use the 1/16 hex wrench to torque the setscrew to 4.5 to 5.5 in-lb (0.5 to 0.6 N•m).



↑ Torque to 4.5 to 5.5 in-lb (0.5 to 0.6 N•m).

Fig. 18

NOTICE

To avoid damage, the nozzle (4) must be installed before the needle (6).

To avoid damage to the needle (6) if the nozzle (4) is removed without full gun disassembly, turn the fluid adjustment knob (11) fully counterclockwise to remove pressure from the needle before reassembling the nozzle.

- 5. Grease the needle shaft and piston o-ring. Push the needle/piston assembly into the gun as far as possible. Insert spring (10).
- 6. Turn counterclockwise to fully open the fluid adjustment knob (11). Install the knob hand-tight.

NOTE: If you have an ultra-precision fluid adjustment knob, loosen the set screw to adjust the position of the hash markings for convenient reading.






Fig. 19

313869M 27

Parts





28 313869M

Parts in Common

Ref.	Part	Description	Qty.
1		BODY	1
2	24C205	FLUID PACKING ASSEMBLY	1
3	119348	O-RING (included with Part 4)	1
4	See Table	NOZZLE, fluid (includes Part 3)	1
5	See Table	AIR CAP ASSEMBLY (includes	
		Parts 5a-5d)	
5a		AIR CAP	1
5b √		O-RING	1
5c √		WASHER, UMHWPE	1
5d		PIN, alignment	1
6	See Table	NEEDLE assembly	1
7	24C202	PISTON, needle stop (includes Parts 7a and 7b)	1
7a		SCREW, set, 6-32 UNC x 1/16 in.	1
7b	117559	O-RING	1
10	24C207	SPRING, compression	1
11	210207	KNOB, fluid adjustment	1
	24D065	Ultra-Precision	'
	24R133	Ultra-Precision (for 24P993 and	
		24P994 only)	
	24C204	Indexing	
	24R134	Indexing (for 24P995 and 24P996 only	
	24C203	Lock ring and cap	
14	120538	FITTING, tube, air line,	3
		1/8 npt x 6 mm	
15		FITTING, tube, fluid line,	2
		1/8 npt x 6 mm	
	24C213	Nylon	
	24D046	Stainless steel	
21	289079	RETAINING RING, assembly (includes 5b and 5c)	1
23	114141	TOOL, wrench, hex, 1/16, not	1
		shown	
24	107157	TOOL, wrench, allen, 4 mm, not	1
		shown	
26	101821	TOOL, wrench, allen, 3/16, not	1
		shown (Models without manifold)	
31	24C210	TOOL, wrench, metric, not shown	1
32	24C209	TOOL, nut driver, hex, 10 mm, not shown	1
33	100139	PLUG, pipe, not shown, shipped loose (Models without manifold)	1

Additional Parts for Models with Manifold

Ref.	Part	Description	Qty.
12	24C215	MANIFOLD, gun (includes Parts 13, 14, 15, 19, and 20)	1
13	106456†	O-RING, PTFE, white	2
16	24C206	SCREW, mounting	2
17	24C208	ROD, mounting (includes Part 18)	1
18		SCREW, cap, hex head	1
19	24C212	SCREW, set socket, M8	2
20	112319†	O-RING, FX75, black	3
25	24C211	PLUG, manifold, shipped loose	1

⁻⁻⁻⁻ Not sold separately.

- ✓ Included in Air Cap Seal Kit 289791. See Repair Kits, page 30.
- † Included in Manifold O-Ring Kit 24D827. See **Repair Kits**, page 30.

313869M 29

Repair Kits

	Gun Part Number					Item 6	Item 5	
			Nozzle	Needle/Nozzle	Item 4	Needle	Air Cap	
			Orifice	Kit	Nozzle	Assembly	(Includes seals	
	With	Without	Size	(Includes	(includes	(includes	and alignment	
Spray Type	Manifold	Manifold	in. (mm)	Items 4 and 6)	o-ring)	tip)	pin)	
	24B857	24B877	0.028 (0.7)	24D177	24D174	24C191		
Conventional		24B878	0.035 (0.9)	24C198	24C187	24C192		
Conventional	24M390*	24M392*	0.039 (1.0)	24C221	24C219	24C220	24C182	
Conventional	24B859	24B879	0.043 (1.1)	24C199	24C188	24C193	240102	
Conventional	24B860	24B880	0.051 (1.3)	24C200	24C189	24C194		
	24B861*		0.059 (1.5)	24D178	24D175	24C195		
HVLP	24B862		0.020 (0.5)	24D302	24D296	24C190		
HVLP	24B863	24B881	0.028 (0.7)	24D179	24D176	24C191	24C183	
HVLP	24B864	24B882	0.043 (1.1)	24D305	24D299	24C193	240183	
HVLP	24B865	24B883	0.051 (1.3)	24D306	24D300	24C194		
HiTEch	24B866	24B884	0.028 (0.7)	24D303	24D297	24C191	24D703	
HiTEch	24B867*	24B885*	0.039 (1.0)	24C221	24C219	24C220	240703	
HiTEch	24B868*	24B886*	0.059 (1.5)	24C201	24D275	24C195	24D704	
LVMP	24B869	24B887	0.020 (0.5)	24D277	24D259	24C190		
LVMP	24B870	24B888	0.028 (0.7)	24D278	24D260	24C191		
LVMP	24B871	24B889	0.035 (0.9)	24D279	24D261	24C192		
LVMP	24M391*	24M393*	0.039 (1.0)	24C221	24C219	24C220		
LVMP	24P993	24P995	0.039 (1.0)	24R001	24P999	24C220	24C184	
LVMP	24B872	24B890	0.043 (1.1)	24D280	24D262	24C193		
LVMP	24B873	24B891	0.051 (1.3)	24D281	24D263	24C194		
LVMP	24P994	24P996	0.051 (1.3)	24R002	24R000	24P998		
LVMP	24B874*		0.059 (1.5)	24D284	24D276	24C195		
Air Brush	24B875	24B892	0.028 (0.7)	24C197	24C186	24C191	24D705	

^{*} Needle tip and nozzle exit constructed from tungsten carbide.

30 313869M

Accessories

Kit 24C216, Fittings (1/4 inch)

Part	Description	Qty.
120388	FITTING, tube, air line,	3
	1/8 npt x 1/4 T	
111157	FITTING, tube, fluid line,	2
	1/8 npt x 1/4 T	

Kit 24D143, Robot Adapter Kit Fanuc Paint Mate 200

Compatible with and without manifold.

Kit 24D008, Inlet Air Needle Valve

Includes needle valve and 6mm tube fittings.

Kit 24D827, Manifold O-Rings

Part	Description	Qty.
106456	O-RING, PTFE, white	2
112319	O-RING, FX75, black	3

HVLP Pressure Verification Kit 24C214

For use in checking air cap atomizing and fan pattern air pressure at various supply air pressures. Not to be used for actual spraying.

Install the kit air cap on the gun. Turn on the air to the gun and read the air pressure on the gauge.

NOTE: To be "HVLP compliant," the atomizing and fan pattern air pressure must not exceed 10 psi (70 kPa, 0.7 bar).