

Professional Respirators

The Binks Millennium 3000 meets all contractor respirator needs by removing paint particles from the air to provide a safe environment for professional painters and contractors. Binks distributors can provide fit testing and certification.

The Millennium 3000

The Millennium 3000 Respirator, with its standard configuration, protects against organic vapors and oil-bearing particulate and mists. Representing the finest in traditional respirators, it provides the fit, comfort, durability and protection of a conventional half-mask respirator. The Millennium 3000 features the finest quality facepiece for outstanding comfort and durability. This soft and comfortable silicone facepiece stands up to repeated cleanings and exposure to paints and solvents without deterioration.



WARNING!

Millennium paint spray respirators are not to be used with urethane paints or other paints containing di-isocyanates. Di-isocyanates have a low odor threshold, meaning they are not easily detectable by smell. A dangerous level of di-isocyanates can break through the charcoal filter cartridge before the user is able to smell it. Painters using such paints must use an air-supplied respirator.

MILLENNIUM 3000 CLASSIC HALF-MASK RESPIRATORS

- 40-141 Sm. Respirator, Black Yoke.
- 40-128 Med. Respirator, Silver Yoke.
- 40-143 Lg. Respirator, Gold Yoke.
- 40-1921 Organic Cartridges. Qty. 2.
- 40-1924 Pre-Filters, Oil Resistant. (Use with 40-1925 Covers.) Qty. 10.
- 40-1925 Covers, Oil Resistant. (Use with 40-1924 Pre-Filters.) Qty. 2.
- 40-1928 Tune-Up Kit for all 3000 Respirators. Contents: Cradle Headband, R and L Neckstraps, 2 Inhalation Valves, 2 Cartridge Gaskets, Exhalation Valve, Exhalation Valve Cover.

When Should You Replace Cartridges and Filters?

The serviceable life of cartridges and filters depends on several factors including breathing rate/volume, concentration of contaminants, temperature, and humidity.

- Replace chemical cartridges when you detect odor, taste of vapors, or experience eye, nose or throat irritation.
- Replace prefilters or filters when you experience increased resistance to breathing.
- *When in doubt about the serviceable life of cartridges or filters, replace.*

*Millennium 3000
Filter Replacement
Cartridge*



*Millennium 3000
Filter*

